



NOTE: INSTALL SOLDER MASK DISCS PRIOR TO WAVE SOLDER  
AS SHOWN OVER "BOTTOM SIDE" PADS OF COMPONENTS  
TO BE BOTTOM MOUNTED. (SD1-SD15)

ASSY PART # 07-109-01 &  
ASSY PART # 07-109-02

FOR ASSEMBLY P/N: 07-109-01 & -02  
USE SCHEMATIC # 07-109-XX

NOTES:  
1. GOOP IN ACCORDANCE WITH PRODUCTION S.O.P.

CAUTION:  
THIS ASSEMBLY DRAWING IS PROVIDED FOR USE BY QUALIFIED PERSONNEL.  
TO AVOID RISK OF ELECTRIC SHOCK, REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.  
DO NOT PERFORM ANY SERVICING BEYOND THAT EXPLAINED IN THE OPERATING INSTRUCTIONS.

REV	Date	DESCRIPTION	Ecr(s)/Ecn(s)	Chgd By	Appvd by	Date
3	8/21/03	CHG'D CABLE PREPS 97- TO 99- CHGS PER ECN	N01236	REM		

2	4/24/03	PWB TO -02 ( VER 7) ADDED -02 ASSY CONFIGURATION	N01178	REM		
1	9/16/02	ADDED SHT 3 WHICH ADDS W1-W11 HOOKED UP PER CHART & AS SHOWN	N00971	REM		
0	5/28/02	CONTROL ISSUE				
REV	Date	DESCRIPTION	Ecr(s)/Ecn(s)	Chgd By	Appvd by	Date
THE INFORMATION CONTAINED ON THIS DRAWING IS PROPRIETARY TO ST. LOUIS MUSIC, INC.						
Signatures:		Date:				
Drawn: REM		10/12/01				
Checked: -						
Released:						
Plot Date: Wed Apr 21, 2004		Drawing Size: C				
Plot Time: 09:53:48		Drawing Type: ASSEMBLY				
Tolerance:		Class Code: NONE				
		Sheet 1 of 2				
Drawing Title:			300W GUITAR PREAMP			
Drawing Number:			07-109-XX			

